
Instructions - Front

REVISED







Vibrato:

A tremulous or pulsating effect produced in an instrumental or vocal tone.

Vibrato the Stem while doing the Push technique. The sound changes according to the vibration.



#### Portamento:

A continuous gliding movement from one tone to another. Play songs as you slide your fingers. It sounds like a grass whistle.



### Wah-wah:


A musical special effect to produce voice-like tones. Open and close the mouth while pushing the Stem switch.

A Mouth Technique does not work while using the headphones.

**STEP (7)** Output terminal / DC 5V terminal (optional)

How to connect Headphones and AC adapter

No headphones or AC adapter included.



## 3.5mm Stereo mini jack

This is for 3.5mm stereo mini plug. You can connect your headphones here.

· You will hear the sound from the speaker while using headphones,

· Mouth Technique does not work while using headphones.

· Set the volume low first and then adjust it while using headphones to protect your hearing.

A It's not unusual to hear some noises from the amplifier or speakers.

⚠ While using headphones, listening at high volume for extended periods of time may cause hearing impairment.

## Note about AC adapter:

Use only the specified AC adapter approved for use with this product. We assume no responsibility whats oever for any damage or loss of the product and/or AC adapters caused by the use of inappropriate adapters or by mishandling of adapters.

# DC5V jack

AC adapter specifications:

- ■Input: AC100-240V, 50-60Hz
- Output: DC5V, Max 1A
- ■Output characteristics: Switching-mode (regulated output voltage) recommended
- ■DC plug size: 2.1mm / 5.5mm
- ■Plug polarity: Center positive (⊕⊕⊕)

This product does not speal


·This product does not play the exact twelve notes. ·There is individual variability in the range and the tone

#### STEP(6) Strap (optional)

Strap:

Use the enclosed strap for carrying the unit and playing for a longer period of time.

There are two rings at the top and the bottom of the Stem switch to attach the strap.



▲ Do not play or handle the unit in an unruly fashion while wearing the strap. It may cause detachment of parts, malfunctions, accidents, or injuries.

# **Important Safety Instructions**

Safety instructions for using AC power source:

Mishandling of power source may cause fatal accidents or serious injuries.

- •Check the voltage rating before you connect the adapter to an electrical outlet to ensure that the required voltage and frequency match the available power source.
- ●Use only the specified AC adapter approved for use with this product.
- •Wipe off dust from the AC adapter plug to avoid electric shock or short-circuit.
- Electric Shock Hazard: Do not handle the AC adapter with wet hands.
- •Unplug the AC adapter after use.
- •Be sure to grasp the adapter itself, not the cable, when disconnecting the AC adapter from the power source.
- Do not piggyback the electrical outlet. It may cause overheating.
- •Do not forcefully bend, twist, or pull the cable, or modify the cable.
- Do not put the cable under furniture, electric appliances, figurines, or any other heavy objects. Damaged cables may cause fire or electric shock.
- Do not use any AC adapter with damaged cable.
- •In the event that the AC adapter becomes damaged or the unit malfunctions, turn the unit off and disconnect the AC adapter immediately.

For more information on Otamatone and fun videos showing hints and techniques are available at the following site:

©YOSHIMOTO KOGYO CO.,LTD. / MAYWA DENKI

http://www.maywadenki.com/otamatone

Produced by CUBE CO., LTD.

http://www.cube-works.co.jp